

HW 2

The noisy ECG signals are provided in the file ecg.hfn.dat and ecg_lfn.dat. The sampling rate of these two signals is 1000 Hz.

- 1. Downsample the signal by 5. Keep only every 5th sample and the sampling rat will be reduced from 1000 Hz to 200 Hz. Plot the downsmpled signals. $(x_d[n]=x[5n])$
- 2. Applied the function of resample in Matlab to perform the above process.

resample Resample uniform or nonuniform data to a new fixed rate.

Y = resample(X,P,Q) resamples the values, X, of a uniformly sampled signal at P/Q times the original sample rate using a polyphase antialiasing filter. If X is a matrix, then resample treats each column as an independent channel.

Compare the results with the original signals.

Due date: PPT report 9:10 a.m. 10/11 2023